

ASPIRE S/ML TIME CHANGE

To change the system time you must goto local 301:

1. Leave handset on hook
2. Press Call button (located on right hand side of telephone)
3. Enter 828
4. Two digits for the hour (24 hour clock, 13:00 = 1pm)
5. Two digits for the minutes (00-59)
6. Press SPK to hang up.

If you have any questions or problems, please call 604-283-9062 for assistance.